

WOOD THAT WORKS

DAVE & MARJI ROY




WHIRLWIND

© 1983



Spiral
Wheels

Front



Winding
Knob

Back

DIRECTIONS FOR OPERATING WHIRLWIND:

To Wind: Locate the winding knob on the back of the sculpture.
(See back view above.)

Turn winding knob clockwise until it can not be turned any more. Do not remove the tape attached to the spring. This keeps the spring from winding off of the spool.

To Start: Turn both spiral wheels clockwise.